HellermannTyton

Welcome



Broadband... where you need it

The fibre extension kit allows you to move your broadband router to a more 'central' location in your property. More often than not, the fibre entry point is at the front of the house and not always where you would want to position your router.

The fibre extension kit, provides you with flexibility to move your router to another, more central room (up to 30m). Not only can you have your broadband router in a more convenient location, but it could also improve the wifi coverage around your property.

* With several model variations available, please check the front outer label to identify you have the correct product/connector type. Scan for info & videos



Installation videos and PDF instructions are available online.

Scan the QR code with your smart phone or tablet to access video instructions and additional information.

What's in the hox

Fibre Wall Outlet

This lives near your modem



This lives inside the outlet




Caution: Laser

Do not look into heam



Protective sock For taking the connector through the wall.





Nail and P Clip For securing over doorways and long sections.



Wall fixings* Screws and wall

pluas. *Check the wall plugs are suitable for your

wall type.



- · 6mm drill bit
- · 12mm drill bit (if routing through a wall)
- Spirit level
- · Smart phone to obtain installation instructions / videos
- · Fibre patch lead





Wall routing guide Fittings for taking fibre through the wall to another room




Internal corner routing guide




External corner routing guide

Setup guide


Fitting the fibre outlet to the wall. Position the outlet where you'd like your router to be located.



Mark on the wall where the screw holes need to go.




Use suitable drill bit to drill 2x holes in the wall and insert suitable wall fixings.



Thread plug 1 through the hole in the base of the wall outlet.




Screw outlet to wall and twist to adjust and straighten.



Remove adaptor from the outlet.



Remove dust caps on plug 2 and the adaptor (Careful do not touch the plug tip).



(7) Push plug 2 into adaptor.




(8) Wind plug 2 fibre around in a loop on top of the spool and slot the adaptor into the holder on the spool.



Ensure adaptor pins are facing upwards.




Fit the **spool** into the **outlet**. Listen for the "click".



Unwind plug 1 to your incoming fibre point and connect.


Routing Through the Home. Use fibre guides to maintain minimum bend radius round corners and doors.




Ensure surfaces are dust-free prior to sticking Corner routing guides.




2 Corner routing guides are supplied with a self-adhesive backing strip.




Peel off adhesive strip and hold down for 5 secs to stick.



Use the internal corner routing guide to go inside of bends i.e internal corners and up along door frames architraves, skirting boards and walls.



When routing over doorways, P-clips should be used to secure the fibre.






Use the external corner routing guides to go outside of bends i.e around the top of door frames and external corners on architraves, skirting boards and walls.


Routing Through the Wall. Use fibre guides to protect fibre and cover drill holes when going between walls.




 Use suitable drill bit to drill a hole through the wall and clean away dust.



From the other side, push a long screwdriver or equivalent through the hole. Tape the flat end of the protective sock to the screwdriver using the supplied adhesive tape. Pull the protective sock through the wall.




3 Insert fibre into the slot on the through the wall guide and follow the routing lines. The guide can face in any direction to maintain the minimum bend radius for the fibre.




Once finished, clip the lid in place to secure the fibre.

Final Steps. Connecting your new fibre extension kit to incoming fibre and your router.




Once finished, decorators caulk can be used to secure fibre.




Wind excess fibre back onto spool and return the adaptor to the outlet. Ensure the pins on the adaptor are facing upwards into the outlet.




Remove dust caps on the patch lead and the adaptor (Careful - do not touch the plug tip).



4 Plug a fibre patch lead (not supplied) into the **adaptor** and the other end into the **router**.




Once finished, fit the lid to the **outlet**.



To reopen the outlet, firmly lift from the bottom flap of the lid upwards.

Typical network setup



HellermannTyton

HellermannTyton Data Ltd Waterside House, Edgar Mobbs Way Northampton NN5 5JE, UK www.htdata.co.uk

