












RapidNet Out of Rack

- Instructions d'installation pour le coffret "Out Of Rack"
- Installationsanleitung für die Verkabelung außerhalb von belegten Verteiler schränken
- Frihängande rack för aktiv och/eller passiv utrustning
- Manual de Instalación de Conectividad Out of Rack
- Out of Rack – Manual de Instalação
- Istruzioni di installazione per connettività esterna al rack
- Povezovalna namestitvena navodila izven omare
- A Rack-csatlakozáson kívüli szerelés leírása
- Instrucțiuni de instalare -conectivitate tava depasita
- Montážní návod - Out of Rack konektivita
- Monteringsanvisning - Out Of Rack Connectivity









Do not overtighten - ne pas serrer trop fort - Nicht zu fest anspannen - Överdra inte - No apretar demasiado - Não aperte demasiado - Non stringere troppo - ne zategnite premocno - kerülje a túlhúzást - A nu se supratensiona - Nepretahovat - Ikke stram for mye





CMA-SB45



HellermannTyton

Tel: +44 (0) 1604 706633
www.htdata.co.uk

Stay in touch with us!

